



ASSEMBLY INSTRUCTIONS

FOR THE

ULTRA CARRYING CASE

Thank you for purchasing the Vexilar Ultra Carrying Case. This sheet provides simple instructions on how to use your new case.

Parts Included

- 1 - Ultra Carrying Case Assembly
- 1 - Transducer Support Eye-Bolt
- 1 - Eye Bolt-Nut
- 2 - Electrical Terminals



1. Crimp the two electrical terminals onto the power cord of your Vexilar flasher. Push the terminals through the rubber grommet, one at a time, in the top of the battery compartment and feed the wire down into it.
2. Remove the two screws that hold the battery door in place on the bottom of the Ultra Case. Plug the two terminals on your power cord into the fully insulated male terminals in the battery compartment's wire harness. Be sure to match wire colors to get proper polarity.
3. If you will be using a Dual Beam transducer, open the plugged holes for the dual beam switch. These holes are visible at the top inside of the battery compartment.
4. Install your battery into the battery compartment making sure the battery terminals are positioned opposite the on/off switch. Plug the two female terminals in the wiring harness onto your battery, red to positive and black to negative.
5. Reattach the battery door making sure that no wires will be pinched when the door is tightened into place. Do not over-tighten the screws.
6. Place your flasher unit between the gimbal arms and use your gimbal knobs to secure your flasher into place. Plug in the power cord and make sure there is enough slack to allow rotation.
7. Turn on the Master Power Switch and then turn on your flasher. It should come on and show a light at the zero position on the display. **The Master Power Switch must be ON when charging the battery.**
8. Plug your transducer into your flasher and then push the transducer into the appropriate transducer holder at the back of the unit. Wrap extra cable behind the tackle box.
9. Thread the nut onto the eye bolt. Thread the eye-bolt into the one of the holes at the very front or sides of the case. Back off the nut until it is tight against the case. This keeps the eye-bolt securely in place. You can hang a Vexilar Ice-ducer from the eye instead of using the float if desired.

Vexilar accessories can be mounted to the case using the pre-drilled holes in the handle. For a complete list of accessories, please see your local retailer or visit us at www.vexilar.com.
